

## Ultrasonic sensor UB400-F42-UK-V95




## Features

- Relay output for high power
- Extremely small unusable area
- TEACH-IN
- Interference suppression (adjustable width of sound cone in close range)
- Temperature compensation
- NO/NC selectable

## Electrical connection


Standard symbol/Connections:



## Connector V95



## Dimensions



## Technical data



### General specifications

Sensing range	40 ... 400 mm
Adjustment range	50 ... 400 mm
Unusable area	0 ... 40 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 390 kHz
Response delay	approx. 50 ms

### Indicators/operating means

LED green	permanently green: Power on
LED yellow	permanent: switching state switch output
	flashing: TEACH-IN function
LED red	normal operation: "fault"
	TEACH-IN function: no object detected

### Electrical specifications

Operating voltage	20 ... V DC ... 253 V AC
No-load supply current $I_0$	$\leq 60$ mA

### Output

Output type	1 relay output
Repeat accuracy	$\leq 0.5$ % of switching point
Rated operational current $I_e$	3 A
Switching frequency $f$	$\leq 8$ Hz
Range hysteresis $H$	1 % of the set operating distance
Temperature influence	$\pm 1$ % of full-scale value

### Standard conformity

Standards	EN 60947-5-2
-----------	--------------

### Ambient conditions

Ambient temperature	-25 ... 70 °C (248 ... 343 K)
Storage temperature	-40 ... 85 °C (233 ... 358 K)

### Mechanical specifications

Protection degree	IP65
Connection	Connector V95 (7/8"-16 UN 2A), 5-pin
Material	
Housing	PBT
Transducer	epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT
Mass	260 g

**Safety notes:**

The supply circuit is separated from the relay circuit by basic insulation.

Safety class II is only guaranteed when using the accessorial connector cable. The connector cable may only be separated from the unit when the power is off.

**CAUTION:**

The UB...-F42(S)-UK-V95 ultrasonic sensor is not suitable for use in environments subject to explosion hazards.

Conformity: EN 60947-5-2  
Housing insulation: Safety class II  
Degree of contamination: 3  
Overvoltage category: III

**Parameterisation:**

You can use 2 keys to parameterise the sensor. In order to start the switch point 1 learning mode, press the A1 key; in order to start the switch point 2 learning mode, press the A2 key.

If you keep both keys pressed as you switch on the power supply, the sensor will switch over to the sensitivity adjustment mode of operation.

In case the parameterisation procedure is not completed within 5 minutes, the sensor will discontinue the process and retain all previous settings.

**Teaching in switch points:**

Teaching in A1 switch point by pressing A1 key.

Keep A1 key pressed for > 2 s      The sensor enters the switch point 1 learning mode

Position target object in the desired distance      The sensor indicates via LED lights whether the target object has been detected. In case the object has been detected, the yellow LED will flash; if the object has not been detected, the red LED flashes.

Briefly press the A1 key      The sensor completes the switch point 1 TEACH-IN process and saves this value in non-volatile memory. In the event of an uncertain object (flashing red LED), the value learned is invalid. The system exits the TEACH-IN mode.


Analogously, the A2 switch point is learned in the same fashion as described above using the A2 key.

**Switching hysteresis operation mode <--> switch point/window operation mode:**




Keep both A1 and A2 keys pressed      The sensor indicates the current operation mode through the green LED.  
permanent green: Switch point/window operation mode  
flashing green: Hysteresis operation mode

after 2 seconds:      The sensor changes the operation mode which can be identified through the green LED.  
permanent green: Switch point/window operation mode  
flashing green: Hysteresis operation mode

Release keys      The green LED of the sensor keeps indicating the operation mode selected for additional 5 seconds

**UB400-F42-UK-V95****Characteristic curves/additional information****Characteristic response curves**

Curve 1: flat plate 100 mm x 100 mm  
Curve 2: round bar, Ø 25 mm

**Possible operating modes****1. Switch point operation****2. Window operation****3. Hysteresis operation****4. Object presence detection mode**

A1 → ∞, A2 → ∞: Sensor detects object presence within sensing range

**Note** A1 → ∞, A2 → ∞ means: cover sensor with hand or remove all objects from sensing range


### Suppression of disturbing targets

Some types of installation or particular conditions during operation of an ultrasonic sensor may admit that undesired objects (such as shelf brow posts, edges of machines) are closer than the actual target as they enter the recording range. In this case, the sensor would normally detect these objects rather than the desired target. So in order to ensure an error-free operation, it may be necessary to suppress those objects.


Objects can be suppressed if they meet the following conditions:

- The disturbing target must not hide the actual target completely.
- The amplitude of the disturbing signal must be smaller than the amplitude of the desired signal.
- The disturbing target must remain in the edge region of the sound lobe and must not enter its center.

#### Sound lobe



The suppression of the disturbing target is effected through reduction of the response sensitivity. This figure shows its effect on the response characteristics of the sensor. The sensor is preset on step 1 by the manufacturer.



### Sensitivity adjustment for suppression of disturbing targets

Remove the actual target object from the detection range.

Keep A1 and A2 keys pressed as you switch on power supply

The sensor enters the sensitivity adjustment mode of operation.

The sensor sensitivity can be adjusted in 24 steps.

Step 1 = high response

Step 24 = low response

Briefly press the A1 key

Response is increased. The LED lights indicate the actual state of the sensor.

- flashing red: no disturbing target detected
- flashing yellow: disturbing target detected
- permanent red: upper setting limit is reached.

Briefly press the A2 key

Response is decreased. The LED lights indicate the actual state of the sensor.

- flashing red: no disturbing target detected
- flashing yellow: disturbing target detected
- permanent red: lower setting limit is reached.

Press both A1 and A2 keys at once

Exiting sensitivity adjustment. The sensor response is saved in non-volatile memory.

In the event the sensitivity adjustment is not exited through this procedure, the sensor will exit this operation mode automatically after 5 minutes, and the previous sensitivity value remains valid.

### Accessories

**Cable connector**

V95-W-2M-PVC

**Mounting aid**

MH 04-3505

MHW 11