Ultrasonic sensor UB500-30GM-E0-V15

Features

- Switch output
- 5 different output functions can be set
- TEACH-IN input
- Synchronisation options
- Deactivation option



CE

Technical data

Dimensions

General specifications	
Sensing range	60 500 mm
Unusable area	0 60 mm
Standard target plate	100 mm x 100 mm
Iransducer frequency	approx. 380 KHZ
Indicators/operating magne	approx. So ms
I ED green	"Power on" TEACH-IN function object detected
LED yellow	indication of the switching state TEACH-IN function-no object detected
LED red	"Error". object uncertain
Electrical specifications	· , · · , · · · · · · · ·
Operating voltage	20 30 V DC , ripple 10 % _{SS}
No-load supply current I0	≤ 60 mA
Input	
Input type	1 TEACH-IN input, operating distance 1: -U _R (-U _R +2 V), operating distance 2: (+U _R -2 V) +U _R 1
	synchronous input level 0: -U _R (-U _R + 1 V), level 1: (-U _R + 5 V) +U _R
	Input impedance 27 kOhm
Pulse length	Synchronisation pulse: \geq 100 μ s
	Synchronisation pulse pause: \geq 100 µs
Synchronisation frequency	
Multiplex operation	\leq 150/n Hz = number of sensors
Output	
Output type	1 switch output E0/E1, npn, normally open/closed, programmable
Repeat accuracy	≤1 %
Rated operational current Ie	200 mA, short-circuit/overload protected
Voltage drop U _d	≤ 3 V
Switching frequency f	max. 13 Hz
Range hysteresis H	\leq 1 % of the set operating distance
Temperature influence	0,17 %/K
Standard conformity	
Standards	EN 60947-5-2
Ambient conditions	
Ambient temperature	-25 70 °C (248 343 K)
Storage temperature	-40 85 °C (233 358 K)
Protection degree	IP65
Connection	connector V15 (M12 x 1), 5 pin
Material	
Housing	brass, nickel-plated, plastic components PBT
Transducer	epoxy resin/hollow glass sphere mixture; polyurethane foam
Mass	145 g

Electrical connection

Standard symbol/Connections: (version E0, npn)



Connector V15

Subject to reasonable modifications due to technical advances.

Printed in Germany

039556_ENG.xml

2003-03-25

UB500-30GM-E0-V15

Characteristic curves/additional information

Characteristic response curves



Curve 1: flat plate 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

Programmed switching output function



Object detected: Switch output closed No object detected: Switch output open

LED-Window



Function

Synchronization

The sensor features a synchronization input for the suppression of mutual interference. It can be synchronized by applying a square wave voltage. The falling edge of a synchronization pulse at the synchronization input starts a measuring cycle. A low level > 1 s or an open synchronization input will result in the non-synchronized normal operation of the sensor. A high level at the synchronization input disables the sensor. Synchronization cannot be performed during TEACH-IN and vice versa.

Two operating modes are possible:

- 1. The sync. inputs of 2 ... 5 Sensors are connected with each other. The sensors synchronize themselves and operate cyclically (multiplex mode).
- 2. Multiple sensors can be controlled by the same synchronization signal. The sensors are synchronized
- 3. The synchronization pulses are sent cyclically to individual sensors. The sensors operate in multiplex mode.

In case of synchronized operation, the response time of the sensor increases due to a longer measuring cycle time caused by synchronization.

Note:

If the option for synchronization is not used, the synchronization input has to be connected to ground (0V) or the sensor has to be operated via a V1 cable connector (4-pin).

Setting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage -UB or +UB to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with -UB, A2 with +UB.

Five different output functions can be set:

I	
Function	TEACH-IN procedure
Window mode, close function	 Set object to near switching point Teach switching point A1 with -UB Set object to far switching point Teach switching point A2 with +UB
Window mode, open function	 Set object to near switching point Teach switching point A2 with +UB Set object to far switching point Teach switching point A1 with -UB
1 switching point, close function	 Set object to near switching point Teach switching point A2 with +UB Cover sensor or remove all objects from sensing range Teach switching point A1 with -UB
1 switching point, open function	 Set object to near switching point Teach switching point A1 with -UB Cover sensor or remove all objects from sensing range Teach switching point A2 with +UB
Detection of object presence	 Cover sensor or remove all objects from sensing range Teach switching point A1 with -UB Teach switching point A2 with +UB

Ultrasonic sensor

Default setting of switching points: A1 = blind range, A2 = nominal distance

Displays in dependence on operat- ing mode	Green LED	Red LED	Yellow LED
Teach switching point Object detected	Flashing	Off	Off
No object detected	Flashing	Off	On
Object uncertain (TEACH-IN invalid)	Off	Flashing	Off
Normal operation	On	Off	Switching state
Interference (e.g. compressed air)	Off	Flashing	Previous state