


Features

- · Parameterisation interface for the application-specific adjustment of the sensor setting via the service program ULTRA 2001
- Current and voltage output
- · Synchronisation options
- · Adjustable acoustic power and sensitivity
- Temperature compensation


Electrical connection


Standard symbol/Connection: (version IU)



Core colours in accordance with EN 60947-5-2.

Dimensions





Technical data

CE

General specifications

Sensing range Adjustment range 30 ... 300 mm 50 ... 300 mm Unusable area 0 ... 30 mm 100 mm x 100 mm approx. 380 kHz Standard target plate Transducer frequency Response delay 21 ms minimum 63 ms factory setting

Indicators/operating means

LED green

permanent: Power-on flashing: Standby mode or TEACH-IN function object detected permanent: object in evaluation range LED yellow 1

flashing: TEACH-IN function LED yellow 2

permanent: object in detection range flashing: TEACH-IN function

permanent: temperature/TEACH-IN plug not connected flashing: fault or TEACH-IN function object not detected I FD red

Temperature/TEACH-IN connectemperature compensation , TEACH-IN for evaluation range , output function set-

Electrical specifications

Operating voltage 10 ... 30 V DC , ripple 10 $\%_{SS}$ Power consumption P₀

Interface Interface type RS 232, 9600 Bit/s, no parity, 8 data bits, 1 stop bit

Input/Output

Synchronisation bi-directional 0 level -U_B...+1 V 1 level: +4 V...+U_B

input impedance: > 12 KOhm

synchronisation pulse: \geq 100 μ s, synchronisation interpulse period: \geq 2 ms Synchronisation frequency

Common mode operation ≤ 95 Hz

Multiplex operation \leq 95/n Hz, n = number of sensors Output

Output type 1 current output 4 ... 20 mA

1 voltage output 0 ... 10 V Resolution evaluation range [mm]/4000, but \geq 0,05 mm

Deviation of the characteristic ≤ 0,2 % of full-scale value Repeat accuracy < 0.1 % of full-scale value current output: ≤ 500 Ohm Load impedance

Voltage output: ≥ 1000 Ohm Temperature influence

≤ 2 % from full-scale value (with temperature compensation) ≤ 0.2 %/K (without temperature compensation)

Standard conformity EN 60947-5-2 Standards

Ambient conditions Ambient temperature -25 ... 70 °C (248 ... 343 K) Storage temperature

Mechanical specifications -40 ... 85 °C (233 ... 358 K)

Protection degree sensor head: IP67

connector sensor head/controller unit: IP52 connector V15 (M12 x 1), 5 pin Connection

Material stainless steel 1.4303 plastic parts PBT Housing

Transducer epoxy resin/hollow glass sphere mixture; polyurethane foam

Mass 260 g 114498_ENG.xml



Description of the sensor functions

This ultrasonic sensor features a four-pole temperature/TEACH-IN plug, that can be connected in four different positions. These have the following significance.

Plug position	Meaning
A1	TEACH-IN evaluation limit A1
A2	TEACH-IN evaluation limit A2
E2/E3	Rising/falling ramp/output characteristic of the voltage output by zero point
Т	Temperature compensation

Description of the TEACH-IN procedure

TEACH-IN the evaluation limits 1 or 2

- Cut supply voltage
- Remove TEACH-IN plug
- Restore supply voltage (Reset)
- Set object to desired switching point
- Connect TEACH-IN plug in pos. A1 or A2. This teaches the evaluation limits A1 or A2.
- The TEACH-IN procedure is controlled with the LED. The green LED flashes, when object is detected, the red LED flashes when no object is detected.
- Connect TEACH-IN plug in pos. T. This completes the TEACH-IN procedure and saves the distance.
- The sensor works in normal mode

TEACH-IN the analogue function

- Cut supply voltage
- Remove TEACH-IN plug
- Restore supply voltage (Reset)
- Connect TEACH-IN plug in pos. E2/E3. By multiple plugging, three different modes of operation can be set in cyclical sequence:
- 1) rising ramp, LED A2 flashes,
- 2) falling ramp, LED A1 flashes,
- 3) zero line, LED A1 and A2 flash
- Connect TEACH-IN plug in pos. T. This completes the TEACH-IN procedure and saves the mode of operation.
- The sensor works in normal mode

Synchronisation

The sensor features a synchronisation input for the suppression of mutual interference.. If this input is not used, the sensor will operate using an internally generated clock rate. It can be synchronised by applying a square wave voltage. A falling edge leads to the transmission of a single ultrasonic pulse. A low level ≥ 1 s or an open synchronisation input will result in the normal operation of the sensor. A high level > 1 s will result in the standby mode of the sensor (indicator green LED). Synchronisation cannot be performed during TEACH-IN and vice versa.

Multiple operating modes are possible:

- 1. Two to five sensors can be synchronised by interconnecting their synchronisation inputs. In this case, the sensors alternately transmit ultrasonic pulses.
- 2. Multiple sensors can be controlled by the same synchronisation signal. The sensors are synchronised.
- 3. The synchronisation pulses are sent cyclically to individual sensors. The sensors operate in multiplex mode.
- 4. A high level at the synchronisation input disables the sensor.

The response time increases when the sensor is synchronised, because the synchronisation increases the measurement cycle time.

Note:

If the option for synchronisation is not used, the synchronisation input has to be connected to ground (0V) or the sensor has to be operated via a V1 cable connector (4-pin).

Default setting

A1: unusable area


A2: nominal sensing range

Mode of operation: rising ramp


UC300-30GM-IUR2-K-V15

Characteristic curves/additional information

Characteristic response curve




Programmed analogue output function




LED Displays/Analogue output

Displays in dependence on operating	Dual	Dual-	LED	LED	analogue
mode	LED	LED	yellow A1	yellow A2	output
	green	red			
TEACH-IN evaluation limit A1					unchanged
object detected	flashes	off	flashes	off	
object not detected	off	flashes	flashes	off	
TEACH-IN evaluation limit A2					unchanged
object detected	flashes	off	off	flashes	
object not detected	off	flashes	off	flashes	
TEACH-IN mode of operation (E2/E3)					unchanged
rising ramp	on	off	off	flashes	
falling ramp	on	off	flashes	off	
zero line	on	off	flashes (syn-	flashes (syn-	
			chronised)	chronised)	
Normal mode			on, if target	on, if target	analogue val-
temperature compensated	on	off	in evaluation	in detection	ue
plug pulled/shorted	off	on	range	range	
Standby	flashes	off	previous	previous	unchanged
			state	state	
Interference (e.g. compressed air)	off	flashes	previous	previous	unchanged
			state	state	or error value

LED-Window



RS 232-connection



Note on communication with the UC-30GM-R2 interface cable

The UC-30GM-R2 interface cable allows for communication with the ultrasonic sensor using the ULTRA 2001 service program. The cable creates a connection between the PC-internal RS 232 interface and the plug-in connection for the temperature/program plug on the sensor. When setting up the connection on the sensor, make certain the plug is lined up correctly; otherwise no communication will be possible. The protrusion of the round plug must be inserted into the groove of the plug connection on the sensor side and not into the arrow symbol on the sensor.

Adjustable parameter with the service program ULTRA 2001

- Evaluation limits A1 and A2
- Rising/falling ramp/zero line
- Mode of operation
- Sonic speed
- Temperature offset (The inherent temperature-rise of the sensor can be considered in the temperature compensation)
- Expansion of the unusable area (for suppression of unusable area echoes)
- Reduction of the detection range (for suppression of remote range echoes)
- Time of measuring cycle
- Acoustic power (interference of the burst duration)
- Sensitivity
- Behaviour of the sensor in case of echo loss
- Behaviour of the sensor in case of a fault
- Average formation via an allowed number of measuring cycles
- Selection of the parameter set, RS 232 or manually.

Accessories

Mounting aids

BF18

BF18-F

BF30

BF30F

BF5-30

OMH04

Ultrasonic sensor

External temperature probe

UC-30GM-TEMP

Extension cable

UC-30GM-PROG

Programming tools

Service program ULTRA 2001 Interface cable UC-30GM-R2

Process indication- and control unit

DA5-IU-2K-V

Cable sockets *)

V15-G-2M-PVC

V15-W-2M-PUR

^{*)} For additional cable sockets see section "Accessories".